

Tabulka pro převod adresy z decimální soustavy do binární při instalaci digitalizačního převodníku Art.2203-1, digitálních telefonů Art.942-3171-3172-3176, video telefonů Art. 901/D1-3371-3379-3376 a přidavného zvonku.

Přep. S1/2=off Přep. S1/3=off		Nastavení adresy přepínačem DIP								
Adresa des.	Art.2203-1 Kombinace vstunů		1	2	3	4	5	6	7	8
1	1a		ON	OFF						
2	1b		OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF
3	1c		ON	ON	OFF	OFF	OFF	OFF	OFF	OFF
4	1d		OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF
5	1e		ON	OFF	ON	OFF	OFF	OFF	OFF	OFF
6	1f		OFF	ON	ON	OFF	OFF	OFF	OFF	OFF
7	1g		ON	ON	ON	OFF	OFF	OFF	OFF	OFF
8	1h		OFF	OFF	OFF	ON	OFF	OFF	OFF	OFF
9	2a		ON	OFF	OFF	ON	OFF	OFF	OFF	OFF
10	2b		OFF	ON	OFF	ON	OFF	OFF	OFF	OFF
11	2c		ON	ON	OFF	ON	OFF	OFF	OFF	OFF
12	2d		OFF	OFF	ON	ON	OFF	OFF	OFF	OFF
13	2e		ON	OFF	ON	ON	OFF	OFF	OFF	OFF
14	2f		OFF	ON	ON	ON	OFF	OFF	OFF	OFF
15	2g		ON	ON	ON	ON	OFF	OFF	OFF	OFF
16	2h		OFF	OFF	OFF	OFF	ON	OFF	OFF	OFF
17	3a		ON	OFF	OFF	OFF	ON	OFF	OFF	OFF
18	3b		OFF	ON	OFF	OFF	ON	OFF	OFF	OFF
19	3c		ON	ON	OFF	OFF	ON	OFF	OFF	OFF
20	3d		OFF	OFF	ON	OFF	ON	OFF	OFF	OFF
21	3e		ON	OFF	ON	OFF	ON	OFF	OFF	OFF
22	3f		OFF	ON	ON	OFF	ON	OFF	OFF	OFF
23	3g		ON	ON	ON	OFF	ON	OFF	OFF	OFF
24	3h		OFF	OFF	OFF	ON	ON	OFF	OFF	OFF
25	4a		ON	OFF	OFF	ON	ON	OFF	OFF	OFF
26	4b		OFF	ON	OFF	ON	ON	OFF	OFF	OFF
27	4c		ON	ON	OFF	ON	ON	OFF	OFF	OFF
28	4d		OFF	OFF	ON	ON	ON	OFF	OFF	OFF
29	4e		ON	OFF	ON	ON	ON	OFF	OFF	OFF
30	4f		OFF	ON	ON	ON	ON	OFF	OFF	OFF
31	4g		ON	ON	ON	ON	ON	OFF	OFF	OFF
32	4h		OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF
33	5a		ON	OFF	OFF	OFF	OFF	ON	OFF	OFF
34	5b		OFF	ON	OFF	OFF	OFF	ON	OFF	OFF
35	5c		ON	ON	OFF	OFF	OFF	ON	OFF	OFF
36	5d		OFF	OFF	ON	OFF	OFF	ON	OFF	OFF
37	5e		ON	OFF	ON	OFF	OFF	ON	OFF	OFF

Přep. S1/2=on Přep. S1/3=off		Nastavení adresy přepínačem DIP								
Adresa des.	Art.2203-1 Kombinace vstunů		1	2	3	4	5	6	7	8
65	1a		ON	OFF	OFF	OFF	OFF	OFF	ON	OFF
66	1b		OFF	ON	OFF	OFF	OFF	OFF	ON	OFF
67	1c		ON	ON	OFF	OFF	OFF	OFF	ON	OFF
68	1d		OFF	OFF	ON	OFF	OFF	OFF	ON	OFF
69	1e		ON	OFF	ON	OFF	OFF	OFF	ON	OFF
70	1f		OFF	ON	ON	OFF	OFF	OFF	ON	OFF
71	1g		ON	ON	ON	OFF	OFF	OFF	ON	OFF
72	1h		OFF	OFF	OFF	ON	OFF	OFF	ON	OFF
73	2a		ON	OFF	OFF	ON	OFF	OFF	ON	OFF
74	2b		OFF	ON	OFF	ON	OFF	OFF	ON	OFF
75	2c		ON	ON	OFF	ON	OFF	OFF	ON	OFF
76	2d		OFF	OFF	ON	ON	OFF	OFF	ON	OFF
77	2e		ON	OFF	ON	ON	OFF	OFF	ON	OFF
78	2f		OFF	ON	ON	ON	OFF	OFF	ON	OFF
79	2g		ON	ON	ON	ON	OFF	OFF	ON	OFF
80	2h		OFF	OFF	OFF	OFF	ON	OFF	ON	OFF
81	3a		ON	OFF	OFF	OFF	ON	OFF	ON	OFF
82	3b		OFF	ON	OFF	OFF	ON	OFF	ON	OFF
83	3c		ON	ON	OFF	OFF	ON	OFF	ON	OFF
84	3d		OFF	OFF	ON	OFF	ON	OFF	ON	OFF
85	3e		ON	OFF	ON	OFF	ON	OFF	ON	OFF
86	3f		OFF	ON	ON	OFF	ON	OFF	ON	OFF
87	3g		ON	ON	ON	OFF	ON	OFF	ON	OFF
88	3h		OFF	OFF	OFF	ON	ON	OFF	ON	OFF
89	4a		ON	OFF	OFF	ON	ON	OFF	ON	OFF
90	4b		OFF	ON	OFF	ON	ON	OFF	ON	OFF
91	4c		ON	ON	OFF	ON	ON	OFF	ON	OFF
92	4d		OFF	OFF	ON	ON	ON	OFF	ON	OFF
93	4e		ON	OFF	ON	ON	ON	OFF	ON	OFF
94	4f		OFF	ON	ON	ON	ON	OFF	ON	OFF
95	4g		ON	ON	ON	ON	ON	OFF	ON	OFF
96	4h		OFF	OFF	OFF	OFF	OFF	ON	ON	OFF
97	5a		ON	OFF	OFF	OFF	OFF	ON	ON	OFF
98	5b		OFF	ON	OFF	OFF	OFF	ON	ON	OFF
99	5c		ON	ON	OFF	OFF	OFF	ON	ON	OFF
100	5d		OFF	OFF	ON	OFF	OFF	ON	ON	OFF
101	5e		ON	OFF	ON	OFF	OFF	ON	ON	OFF

Přep. S1/2=off Přep. S1/3=off		Nastavení adresy přepínačem DIP								
Adresa des.	Art.2203-1 Kombinace vstupů		1	2	3	4	5	6	7	8
38	5f		OFF	ON	ON	OFF	OFF	ON	OFF	OFF
39	5g		ON	ON	ON	OFF	OFF	ON	OFF	OFF
40	5h		OFF	OFF	OFF	ON	OFF	ON	OFF	OFF
41	6a		ON	OFF	OFF	ON	OFF	ON	OFF	OFF
42	6b		OFF	ON	OFF	ON	OFF	ON	OFF	OFF
43	6c		ON	ON	OFF	ON	OFF	ON	OFF	OFF
44	6d		OFF	OFF	ON	ON	OFF	ON	OFF	OFF
45	6e		ON	OFF	ON	ON	OFF	ON	OFF	OFF
46	6f		OFF	ON	ON	ON	OFF	ON	OFF	OFF
47	6g		ON	ON	ON	ON	OFF	ON	OFF	OFF
48	6h		OFF	OFF	OFF	OFF	ON	ON	OFF	OFF
49	7a		ON	OFF	OFF	OFF	ON	ON	OFF	OFF
50	7b		OFF	ON	OFF	OFF	ON	ON	OFF	OFF
51	7c		ON	ON	OFF	OFF	ON	ON	OFF	OFF
52	7d		OFF	OFF	ON	OFF	ON	ON	OFF	OFF
53	7e		ON	OFF	ON	OFF	ON	ON	OFF	OFF
54	7f		OFF	ON	ON	OFF	ON	ON	OFF	OFF
55	7g		ON	ON	ON	OFF	ON	ON	OFF	OFF
56	7h		OFF	OFF	OFF	ON	ON	ON	OFF	OFF
57	8a		ON	OFF	OFF	ON	ON	ON	OFF	OFF
58	8b		OFF	ON	OFF	ON	ON	ON	OFF	OFF
59	8c		ON	ON	OFF	ON	ON	ON	OFF	OFF
60	8d		OFF	OFF	ON	ON	ON	ON	OFF	OFF
61	8e		ON	OFF	ON	ON	ON	ON	OFF	OFF
62	8f		OFF	ON	ON	ON	ON	ON	OFF	OFF
63	8g		ON	ON	ON	ON	ON	ON	OFF	OFF
64	8h		OFF	OFF	OFF	OFF	OFF	OFF	ON	OFF

Přep. S1/2=on Přep. S1/3=off		Nastavení adresy přepínačem DIP								
Adresa des.	Art.2203-1 Kombinace vstupů		1	2	3	4	5	6	7	8
102	5f		OFF	ON	ON	OFF	OFF	ON	ON	OFF
103	5g		ON	ON	ON	OFF	OFF	ON	ON	OFF
104	5h		OFF	OFF	OFF	ON	OFF	ON	ON	OFF
105	6a		ON	OFF	OFF	ON	OFF	ON	ON	OFF
106	6b		OFF	ON	OFF	ON	OFF	ON	ON	OFF
107	6c		ON	ON	OFF	ON	OFF	ON	ON	OFF
108	6d		OFF	OFF	ON	ON	OFF	ON	ON	OFF
109	6e		ON	OFF	ON	ON	OFF	ON	ON	OFF
110	6f		OFF	ON	ON	ON	OFF	ON	ON	OFF
111	6g		ON	ON	ON	ON	OFF	ON	ON	OFF
112	6h		OFF	OFF	OFF	OFF	ON	ON	ON	OFF
113	7a		ON	OFF	OFF	OFF	ON	ON	ON	OFF
114	7b		OFF	ON	OFF	OFF	ON	ON	ON	OFF
115	7c		ON	ON	OFF	OFF	ON	ON	ON	OFF
116	7d		OFF	OFF	ON	OFF	ON	ON	ON	OFF
117	7e		ON	OFF	ON	OFF	ON	ON	ON	OFF
118	7f		OFF	ON	ON	OFF	ON	ON	ON	OFF
119	7g		ON	ON	ON	OFF	ON	ON	ON	OFF
120	7h		OFF	OFF	OFF	ON	ON	ON	ON	OFF
121	8a		ON	OFF	OFF	ON	ON	ON	ON	OFF
122	8b		OFF	ON	OFF	ON	ON	ON	ON	OFF
123	8c		ON	ON	OFF	ON	ON	ON	ON	OFF
124	8d		OFF	OFF	ON	ON	ON	ON	ON	OFF
125	8e		ON	OFF	ON	ON	ON	ON	ON	OFF
126	8f		OFF	ON	ON	ON	ON	ON	ON	OFF
127	8g		ON	OFF						
128	1a		OFF	ON						

Přep. S1/2=off Přep. S1/3=on		Nastavení adresy přepínačem DIP								
Adresa des.	Art.2203-1 Kombinace vstupů		1	2	3	4	5	6	7	8
129	1b		ON	OFF	OFF	OFF	OFF	OFF	OFF	ON
130	1c		OFF	ON	OFF	OFF	OFF	OFF	OFF	ON
131	1d		ON	ON	OFF	OFF	OFF	OFF	OFF	ON
132	1e		OFF	OFF	ON	OFF	OFF	OFF	OFF	ON
133	1f		ON	OFF	ON	OFF	OFF	OFF	OFF	ON
134	1g		OFF	ON	ON	OFF	OFF	OFF	OFF	ON
135	1h		ON	ON	ON	OFF	OFF	OFF	OFF	ON
136	2a		OFF	OFF	OFF	ON	OFF	OFF	OFF	ON

Přep. S1/2=off Přep. S1/3=on		Nastavení adresy přepínačem DIP								
Adresa des.	Art.2203-1 Kombinace vstupů		1	2	3	4	5	6	7	8
155	4d		ON	ON	OFF	ON	ON	OFF	OFF	ON
156	4e		OFF	OFF	ON	ON	ON	OFF	OFF	ON
157	4f		ON	OFF	ON	ON	ON	OFF	OFF	ON
158	4g		OFF	ON	ON	ON	ON	OFF	OFF	ON
159	4h		ON	ON	ON	ON	ON	OFF	OFF	ON
160	5a		OFF	OFF	OFF	OFF	OFF	ON	OFF	ON
161	5b		ON	OFF	OFF	OFF	OFF	ON	OFF	ON
162	5c		OFF	ON	OFF	OFF	OFF	ON	OFF	ON

Přep. S1/2=off Přep. S1/3=on		Nastavení adresy přepínačem DIP								
Adresa des.	Art.2203-1 Kombinace vstunů		1	2	3	4	5	6	7	8
137	2b		ON	OFF	OFF	ON	OFF	OFF	OFF	ON
138	2c		OFF	ON	OFF	ON	OFF	OFF	OFF	ON
139	2d		ON	ON	OFF	ON	OFF	OFF	OFF	ON
140	2e		OFF	OFF	ON	ON	OFF	OFF	OFF	ON
141	2f		ON	OFF	ON	ON	OFF	OFF	OFF	ON
142	2g		OFF	ON	ON	ON	OFF	OFF	OFF	ON
143	2h		ON	ON	ON	ON	OFF	OFF	OFF	ON
144	3a		OFF	OFF	OFF	OFF	ON	OFF	OFF	ON
145	3b		ON	OFF	OFF	OFF	ON	OFF	OFF	ON
146	3c		OFF	ON	OFF	OFF	ON	OFF	OFF	ON
147	3d		ON	ON	OFF	OFF	ON	OFF	OFF	ON
148	3e		OFF	OFF	ON	OFF	ON	OFF	OFF	ON
149	3f		ON	OFF	ON	OFF	ON	OFF	OFF	ON
150	3g		OFF	ON	ON	OFF	ON	OFF	OFF	ON
151	3h		ON	ON	ON	OFF	ON	OFF	OFF	ON
152	4a		OFF	OFF	OFF	ON	ON	OFF	OFF	ON
153	4b		ON	OFF	OFF	ON	ON	OFF	OFF	ON
154	4c		OFF	ON	OFF	ON	ON	OFF	OFF	ON

Přep. S1/2=off Přep. S1/3=on		Nastavení adresy přepínačem DIP								
Adresa des.	Art.2203-1 Kombinace vstunů		1	2	3	4	5	6	7	8
163	5d		ON	ON	OFF	OFF	OFF	ON	OFF	ON
164	5e		OFF	OFF	ON	OFF	OFF	ON	OFF	ON
165	5f		ON	OFF	ON	OFF	OFF	ON	OFF	ON
166	5g		OFF	ON	ON	OFF	OFF	ON	OFF	ON
167	5h		ON	ON	ON	OFF	OFF	ON	OFF	ON
168	6a		OFF	OFF	OFF	ON	OFF	ON	OFF	ON
169	6b		ON	OFF	OFF	ON	OFF	ON	OFF	ON
170	6c		OFF	ON	OFF	ON	OFF	ON	OFF	ON
171	6d		ON	ON	OFF	ON	OFF	ON	OFF	ON
172	6e		OFF	OFF	ON	ON	OFF	ON	OFF	ON
173	6f		ON	OFF	ON	ON	OFF	ON	OFF	ON
174	6g		OFF	ON	ON	ON	OFF	ON	OFF	ON
175	6h		ON	ON	ON	ON	OFF	ON	OFF	ON
176	7a		OFF	OFF	OFF	OFF	ON	ON	OFF	ON
177	7b		ON	OFF	OFF	OFF	ON	ON	OFF	ON
178	7c		OFF	ON	OFF	OFF	ON	ON	OFF	ON
179	7d		ON	ON	OFF	OFF	ON	ON	OFF	ON
180	7e		OFF	OFF	ON	OFF	ON	ON	OFF	ON